

PRODUCT DESCRIPTION: INFLATABLE TUBES INTENDED FOR AQUA PARKS

product is intended for use in Aqua parks for riding on the "lazy river" or on slides. It is not intended for use on lakes and rivers. The product is not intended for towing.

The product is made of high-quality raw materials, highly flexible, environmentally friendly PVC, samples of which have been tested in SGS laboratories. Each production process of the product has been subjected to strict quality control and fully meets the utility requirements.

PREPARING THE PRODUCT FOR USE.

STEP 1:



Straighten the product on a flat, smooth surface without sharp protrusions.

STEP 2:



Open the valve and use a pump with the appropriate inflation tip.

STEP 3:




Stop pumping when recommended pressure has been reached. Press the nut A

valve as shown in Figure A. If you want to release air, insert a plastic tube into the valve as shown in Figure B.



STEP 4:



When moving, lift the product so that it does not touch the ground or sharp edges! Dragging on concrete or other rough surfaces will damage the product.

MAINTENANCE AND PERIODIC INSPECTIONS.

Check the pressure regularly, especially when the ambient temperature changes. If the air pressure exceeds the recommended values, the product may be damaged, deformed, or the welds may crack. Air expands and increases the pressure inside the product when exposed to direct sunlight.

NOTE: THE HIGHER THE AMBIENT TEMPERATURE, THE LOWER AIR PRESSURE TO INFLATE THE PRODUCT!


Regularly check the condition of this product before use. Immediately remove any damaged products from service. Punctured, deformed material or cracks caused by exceeding the recommended working pressure can be repaired using the repair kit patches supplied with product and suitable PVC glue (not included). **STORING**

UNUSED PRODUCTS: Rinse the product with clean water after use to remove any residual chlorine and reduce exposure time. If you plan to store the product, it is important to clean it thoroughly. After drying, move the product to a dry, shaded, ventilated place. In particular, protect the product from prolonged exposure to sunlight, rain and chemicals. Do not bend the product when the temperature is lower than 15 degrees Celsius. If the product was improperly stored, it will significantly affect the life of the product next season. Do not expose the product to direct sunlight for a long time! Long-term exposure to sunlight significantly shortens the life of the product.

WARNING! THIS PRODUCT IS NOT SUITABLE FOR CHILDREN UNDER 6 YEARS OF AGE.

CHILDREN OVER 6 YEARS OF AGE MAY ONLY USE THIS PRODUCT UNDER ADULT SUPERVISION.

ALWAYS WEAR A LIFE VEST WHEN USING THIS PRODUCT IN DEEP WATER. THIS PRODUCT IS NOT A LIFE SAVING PRODUCT!



Description and explanation of signs that may be found on products.

Read the instructions first!

Number of users, adults/children (May be marked on the product.)

Weight range of user(s):
.. up to... kg
(May be marked on the product.)

Always supervise children in the water.

Designation of internal dimension.
(May be marked on product.)

Make sure you have enough free space so you don't get stuck inside.

Use in pool only.

The device (product) ensures swimming stability. The device requires balancing. (Incorrect options may be crossed out).



Recommended/permitted use

Prohibited use



NO PROTECTION AGAINST DROWNING

RISK OF GETTING STUCK IF SIZE IS NOT CORRECT.

RECOMMENDED OPERATING

PRESSURE: - FOR LAZY RIVER/POOL: 0.04-0.05 BAR (4.0-5.0 kPa)

- FOR WATER SLIDE: 0.02-0.03 BAR (2.0-3.0 kPa)



THIS PRODUCT IS NOT SUITABLE FOR CHILDREN UNDER 6 YEARS OF AGE.